

Precautions for use:

1. Using an incorrect power adapter or USB cable may cause damage to your mobile device.
2. Do not charge near fire or high temperature.
3. Do not direct the light into people's eyes to avoid vision damage.
4. Keep the item in a dry place and do not expose it to an extremely hot, cold or wet surrounding.
5. Keep out of the reach of children
6. Clean the item by means of a damp cloth
7. Do not try to disassemble or repair the item on your own but have it repaired by a professional.

Vorsichtsmaßnahmen für den Gebrauch:

1. Die Verwendung eines falschen Netzteils oder USB-Kabels kann zu Schäden an Ihrem mobilen Gerät führen.
2. Nicht in der Nähe von Feuer oder hohen Temperaturen aufladen.
3. Richten Sie das Licht nicht in die Augen von Personen, um Sehschäden zu vermeiden.
4. Bewahren Sie das Gerät an einem trockenen Ort auf und setzen Sie es keiner extrem heißen, kalten oder nassen Umgebung aus.
5. Außerhalb der Reichweite von Kindern aufbewahren.
6. Reinigen Sie den Artikel mit einem feuchten Tuch.
7. Versuchen Sie nicht, das Gerät selbst zu zerlegen oder zu reparieren, sondern lassen Sie es von einem Fachmann reparieren.